

## **A General Information**

<b>A.1</b>	<b>Information about this user manual.....</b>	<b>A - 1</b>
<b>A.2</b>	<b>Explanation of symbols.....</b>	<b>A - 1</b>
<b>A.3</b>	<b>Customer service.....</b>	<b>A - 2</b>

## **1 Introduction**

<b>1.1</b>	<b>TECHNOLAS® Femtosecond Workstation.....</b>	<b>1 - 1</b>
<b>1.2</b>	<b>Scope of delivery.....</b>	<b>1 - 1</b>
<b>1.3</b>	<b>List of abbreviations.....</b>	<b>1 - 2</b>

## **2 Safety**

<b>2.1</b>	<b>Intended use.....</b>	<b>2 - 1</b>
<b>2.2</b>	<b>Customer's responsibility.....</b>	<b>2 - 1</b>
<b>2.3</b>	<b>Personnel requirements.....</b>	<b>2 - 2</b>
<b>2.4</b>	<b>General hazards.....</b>	<b>2 - 3</b>
2.4.1	Electrical hazard.....	2 - 4
2.4.2	Laser radiation hazard.....	2 - 4
2.4.3	Fire hazard.....	2 - 5
2.4.4	Mechanical hazard.....	2 - 5
2.4.5	Damage to property.....	2 - 5
<b>2.5</b>	<b>Warning signals and alarms.....</b>	<b>2 - 6</b>
<b>2.6</b>	<b>Safety devices.....</b>	<b>2 - 6</b>
<b>2.7</b>	<b>Labeling.....</b>	<b>2 - 7</b>
2.7.1	Labels in the entrance area to the operating room.....	2 - 7
2.7.2	Labels on the laser system.....	2 - 9

## **3 Transportation and Storage**

<b>3.1</b>	<b>Transportation.....</b>	<b>3 - 1</b>
<b>3.2</b>	<b>Visual inspection of the laser system and its packaging.....</b>	<b>3 - 1</b>
<b>3.3</b>	<b>Unpacking of the laser system.....</b>	<b>3 - 2</b>